



### features

- True RMS measurement
- Low set & High set
- Operation hour recording
- Fault & Trip LED indication
- Trip value recording (3 memory)
- Neutral current display
- THD-I display
- Last 30 mins. ampere demand
- Maximum ampere demand
- Selectable 6 IDMT graphs
- 2 output relays
- Programmable software lock
- Selectable frequency (50 / 60 Hz)
- Flush mount



### Technical Specification

Technical data / Setting range

TECHNICAL DATA	Measurement	True RMS Ampere
Power supply	85 ~ 270 VAC / 100 ~340 VDC	
	*16 ~ 36 VDC (model : D24n:- optional)	
Rated current	..5A (../1A upon request)	
Rated frequency	50 / 60 Hz (selectable)	
Relay operation level	≥1.10 x (IDMT), ≥ 1.0 x (DTL)	
C.T. burden@5A	< 0.5 VA	
Tripping contact	SPDT 5A / 240 VAC	
Weight	~ 520 g	
Operating temp.	0° C ~ +55° C	
Standard	IEC : 61000-4-2/4-4/4-5/255-5:1	
SETTING RANGE	Current Setting ( I > )	20 ~ 200% (1% step) over current
Current Setting ( I <sub>E</sub> > )	2 ~ 50% (1% step) earth fault	
High-set ( I >> )	OFF or 20 ~ 1000% (10% step) over current	
High-set ( I <sub>E</sub> >> )	OFF or 20 ~ 1000% (10% step) earth fault	
Time setting ( T <sub>M</sub> I or T <sub>I</sub> )	0.05 ~ 1.0 sec. (0.1 time multiplier step) oc	
Time setting ( T <sub>M</sub> I <sub>E</sub> or T <sub>I</sub> E )	0.05 ~ 1.0 sec. (0.1 sec. step) earth fault	
High-set time ( T <sub>I</sub> >> )	0.03 ~ 20.0 sec. (0.1 sec. step)	
High-set time ( T <sub>I</sub> E >> )	0.03 ~ 20.0 sec. (0.1 sec. step)	


### Casing Dimension

35 mm wide DIN Rail mount



### Panel Description

Overview / Button Functions




### Parameter Modes

Modes definition

mode	description
1 I >	To set over current
2 Characteristic I <sub>E</sub> >	Selectable IDMT curves
3 T <sub>M</sub> I > or T <sub>I</sub> >	To set trip time ( Time Multiplier )
4 I >>	To set high set fault (over current)
5 T <sub>I</sub> >>	To set high set trip time (over current)
6 I <sub>E</sub> >	To set fault current
7 Characteristic I <sub>E</sub> >	Selectable IDMT curves (earth fault)
8 T <sub>M</sub> I <sub>E</sub> > or T <sub>I</sub> E >	To set trip time (earth fault)
9 I <sub>E</sub> >>	To set high set trip (earth fault)
0 T <sub>I</sub> E >>	To set high set trip time (earth fault)
6 Trip mem.2	Most recent tripped value
01 to 05	Tripped memory
6 I-Start	View starting fault current
6 Operation hr. x 1000	View Opt. hr. / THD / Amp Demand
6 Software lock	Keypad lock : ON or OFF
71 TripRelay K1 response type	Latching or Non-latching
72 Output relay K2 function	Programmable relay output
72 TripRelay K2 response type	Latching or Non-latching
6 Network frequency	Selectable as : 50 Hz or 60 Hz
6 Standby mode	Running LED bar : ON or OFF

### Wiring Diagram


Wiring connection




## How to do setting

Step by step instruction

When mode display is blank, press **[Select]** button to access to parameter setting mode.



**1** Press **[ Select ]** button while in default mode to access to parameter setting mode:



To scroll thru modes, just press & release the **[Select]** button

**2** Press **[ Up ]** or **[ Down ]** button to adjust desire value

For fast increment or decrement, press and hold the UP or Down button

**3** Press **[ Set ]** to store new value and proceed to the next mode.

Press **[ Cancel ]** button to exit mode or undo changes.

All modes exit automatically if left untouched for more than 20 secs.

## Setting Parameters

Modes 1 2 3 4 5

### 1 I > : To set over current (%)

- Step 1 :** Press **[ Select ]** once to enter mode **1**. Display will show the existing set value. (Range : 20 ~ 200%)
- Step 2 :** Select the desired over current value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **2** or press **[ Cancel ]** to undo changes.

### 2 Characteristic I : To select IDMT curves Over Current

- Step 1 :** Press **[ Select ]** until mode **2** is displayed. Display will show the existing set value. (refer to IDMT Graph)
- Step 2 :** Select the desired IDMT curve using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **3** or press **[ Cancel ]** to undo changes.

### 3 TM<sub>I</sub> or T<sub>I</sub> : To set Time-Multiplier Over Current

- Step 1 :** Press **[ Select ]** until mode **3** is displayed. Display will show the existing set value. (Range : 0.05 ~ 1.0 time-multiplier)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **4** or press **[ Cancel ]** to undo changes.

### 4 I >> : To set High-set over current (%) Over Current

- Step 1 :** Press **[ Select ]** until mode **4** is displayed. Display will show the existing set value. (Range : OFF or 20 ~ 2000 %)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **5** or press **[ Cancel ]** to undo changes.

### 5 T<sub>I</sub> >> : To set High-set trip time (sec.) Over Current

- Step 1 :** Press **[ Select ]** until mode **5** is displayed. Display show : **---** (Disabled -> Mode 4 is set to OFF)  
When mode 4 is not set to OFF :-  
Display will show the existing set value (Range : 0.03 ~ 20.0 sec.)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **6** or press **[ Cancel ]** to undo changes.

### 6 I<sub>E</sub> > : To set High-set trip time (sec.) Earth Fault

- Step 1 :** Press **[ Select ]** until mode **6** is displayed. Display will show the existing set value. (Range : 2 ~ 50 %)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **7** or press **[ Cancel ]** to undo changes.

### 7 Characteristics ( I<sub>E</sub> > ) : To select IDMT curves Earth Fault

- Step 1 :** Press **[ Select ]** until mode **7** is displayed. Display show : **---** (Disabled -> Mode 4 is set to OFF)  
When mode 4 is not set to OFF :-  
Display will show the existing set value (Range : 0.03 ~ 20.0 sec.)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **8** or press **[ Cancel ]** to undo changes.

### 8 TM<sub>E</sub> > or T<sub>E</sub> > : To set Earth Fault trip time Earth Fault

- Step 1 :** Press **[ Select ]** until mode **8** is displayed. Display will show the existing set value. (Range : 0.05 ~ 1.00 sec.)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **9** or press **[ Cancel ]** to undo changes.

### 9 I<sub>E</sub> >> : To set High-set fault (%) Earth Fault

- Step 1 :** Press **[ Select ]** until mode **9** is displayed. Display will show the existing set value. (Range : OFF or 20 ~ 1000 %)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **A** or press **[ Cancel ]** to undo changes.

### A T<sub>E</sub> >> : To set High-set fault trip time Earth Fault

- Step 1 :** Press **[ Select ]** until mode **A** is displayed. Display will show the existing set value. (Range : 0.03 ~ 20.0 sec.)
- Step 2 :** Select the desired value using the **[ Up / (+) ]** or **[ Down / (-) ]** button. Newly selected value will flash.
- Step 3 :** Press **[ Select ]** to store / confirm new value and advance to mode **B** or press **[ Cancel ]** to undo changes.

## Viewing Info

Modes B / C1 to C6

### B, C1 to C6 View tripped memory (7-tripping memories)

- Press **[ Select ]** until mode **B** is displayed. Display will show the most recent tripped memory for phase L1. Continue pressing the **[ Select ]** button to view all tripped memory for phase L2,L3 & E. After phase E for memory **B** is viewed, pressing **[ Select ]** button will go to memory **C1** (phase L1 to E) and then **C2** (phase L1 to E) and so on until **C6** is viewed. Press **[ Cancel ]** button each time to back track each individual phase tripped value. Phase L1,L2,L3 and E will flash once or twice depending on the tripping conditions:-  
**NO FLASH :** Phase did not cause the tripping  
**FLASH ONCE :** Phase cause a low-set trip  
**FLASH TWICE :** Phase cause a high-set trip

### d View Starting fault current value ( I-start )

- Press **[ Select ]** until mode **d** is displayed. Display will show the I-start fault current value. Press **[ Select ]** again to advance to mode **e** or press **[ Cancel ]** to exit mode.

### E View Opt. hr. x 1000 / THD / Amp demand

- Press **[ Select ]** until mode **E** is displayed. Display will show the total operation hour of the device. **[ Select ]** button for 2 seconds. Press **[ Select ]** again to view individual phase. After phase E is viewed, pressing **[ Select ]** will display **E-d** **[ Down / (-) ]** button. Newly selected value will flash. Press **[ Select ]** to store / confirm new value and advance to mode **5** or press **[ Cancel ]** to undo changes.

## Manual ' test trip '

Test device for fault in tripping

**Manual test trip allows the user to test the device for any fault in tripping. To do a manual test trip, follow the instruction below:**

When **NO** mode is selected (mode display is blank),

- i) Press & hold **[ Test ]** button for 5 seconds. The mode display decimal will flash 5 times to indicate 5 seconds count.
  - ii) Release the button when the display show : **E-E**
  - iii) Mode starts to count down from 5 and trips at zero. The display will show : **E-FP** (The mode display decimal will flash 3 times to indicate 3 seconds count)
- To abort test when mode has not counted down to zero, press the **[ Cancel ]** button.

## Reset Trip Memory

Reset recorded trip memories or total trip count

**Press [ Select ] button until mode [A] is displayed.**

If the display show **---** ( NO tripping has occurred ), no resetting is required. If the display show a certain value ( tripping has occurred ), then follow the steps below:-

Press **[ Cancel ]** button and hold for 3 seconds in current mode -> mode **A** (The mode display decimal will flash 3 times to indicate 3 seconds count)

The display will reset to show **E-LF**. To exit, press the **[ Cancel ]** button.

## Special Setting Modes

Modes **L** **R1** **R2** **R3** **F**

User can lock the keypad on the device to avoid unauthorized or accidental adjustment to the settings and to do special settings.

When NO mode is selected (mode display is blank),

- Press [ Select ] and [ Cancel ] button simultaneously and hold for 5 seconds.
- Press [ Up / (+) ] or [ Down / (-) ] button to select or modify
- Press [ Set ] button to confirm and proceed to next mode

**L** Software keypad lock

**OFF** : Parameters modification > Allowed  
**On** : Parameters modification > Not Allowed

**R2** K2 response type

**Lc** : Latching trip signal  
**nLc** : Non-Latching trip signal  
**nA** : Not Available

**R1** Trip relay K1 response type

**Lc** : Latching trip signal  
**nLc** : Non-Latching trip signal

**F** Electrical network system frequency

Electrical network frequency setting:  
**50** = 50 Hz    **60** = 60 Hz

**R2** Output relay K2 function

**LcFP** : Tripping output (Lc or nLc)  
**LcFS** : Low-set fault start signal output (nLc)  
**HcFS** : High-set fault start signal output (nLc)  
**AFS** : Any fault start signal output (nLc)  
**EFtL** : Earth fault trip output (Lc only)  
**OUF** : Device failure output  
**CBF** : Circuit breaker failure output (Lc or nLc)  
**ALr** : Alarm output (nLc)

**-** Standby option

**OFF** : De-activate    **On** : Activate

A flashing decimal on the mode display indicate standby mode is enable. After about 3 minutes of idle and no leakage is detected, running LED bar will be displayed instead of the real time leakage current. Standby mode automatically exits on leakage detection or when any button is depressed. When device trips, standby mode is temporary de-activated until device is reset. Alternatively, simply press [Cancel] button when powering up the device to activate or de-activate standby function.


After Standby mode, the display will show : **End**<>**EEt**.

Press [Set] to confirm all of the above settings or press [Cancel] to go back one previous mode. Press & hold [Cancel] for 3 seconds to exit and abort the modification without saving (previous setting unchanged).

New setting only takes effect when [Set] button is pressed during **End**<>**EEt** is displayed.

## IDMT Graph

Time graph based on Time Multiplier 1.0



Characteristics ( I <sub>E</sub> )	Setting	Description
<b>n3.0</b>	Normal Inverse 3.0 /10	
<b>n1.3</b>	Normal Inverse 1.3 /10	
<b>U.I</b>	Very Inverse	
<b>E.64</b>	Extremely Inverse (0.64 sec)	
<b>L.T.I</b>	Long Time Inverse	
<b>E.I</b>	Extremely Inverse	
<b>d.t.t.</b>	Definite Time	

## Special Setting Modes for model TM-9000c-u240c (communication type)

Modes **R3** **R4** **R5** **R6** **R7** **R8** **R9** **R0** **R1** **R2**

Additional output functions as listed below: (Not applicable for model TM-9000s-U240n)

**R3** Output Relay K3 Function

**LPS** : Lo-set phase overcurrent start signal output  
**LPT** : Lo-set phase overcurrent trip signal output  
**HPS** : Hi-set phase overcurrent start signal output  
**HPT** : Hi-set phase overcurrent trip signal output  
**PHS** : Phase overcurrent start signal output (lo/hi-set)  
**PHT** : Phase overcurrent trip signal output (lo/hi-set)  
**HFS** : Hi-set fault start signal output (either phase:oc/ef)  
**AFS** : Any fault start signal output (any fault condition)

**R3** K3 Response Type

**Lc** : Latching type output for K3  
**nLc** : Non-latching type output for K3

Any of the K3 function can be configured as Lc or nLc type response

**R4** Output Relay K4 Function

**LES** : Lo-set Earth fault start signal output  
**LET** : Lo-set Earth fault trip signal output  
**HES** : Hi-set Earth fault start signal output  
**HET** : Hi-set Earth fault trip signal output  
**EFs** : Earth fault start signal output (lo/hi-set)  
**EFt** : Earth fault trip signal output (lo/hi-set)  
**LFs** : Lo-set Fault Start signal output (either phase)  
**ALr** : pre-Alarm output (>= 95% of phase overcurrent or >= 50% of earth fault setting)

**R4** K4 Response Type

**Lc** : Latching type output for K4  
**nLc** : Non-latching type output for K4

Any of the K4 function can be configured as Lc or nLc type response

**DF** Digital Input Function

**OFF** : De-activate digital input function  
**LEb** : Activate Lo-set Earth fault blocking  
**HEb** : Activate Hi-set Earth fault blocking  
**EFb** : Activate Earth fault blocking (lo/hi-set)  
**LPb** : Activate Lo-set Phase overcurrent blocking  
**HPb** : Activate Hi-set Phase overcurrent blocking  
**PHb** : Activate Phase overcurrent blocking (lo/hi-set)  
**LSb** : Activate Lo-set blocking (either phase)  
**HSb** : Activate Hi-set blocking (either phase)  
**ALb** : Activate all fault blocking  
**R-b** : Activate group B settings  
**RSb** : Activate remote reset when tripped  
**TRP** : Activate remote tripping  
**ECs** : Trip circuit supervision. Test continuity of trip circuit. Only available if K2 set as **OUF**

**bE** Blocking Timer Selection

**OFF** or **On**

Selection of blocking time from 0.1 ~ 10s or Infinite (Ind)  
 Temporarily block the trip timer of the associated fault from timeout (and consequent tripping) to allow time for downstream breaker to trip first.  
 Only available if (dF) digital input function set as blocking function.

**R7** Remote Modbus Programming

**OFF** : Only remote reading of parameters are allowed.  
**On** : Both remote programming and reading of parameters are allowed.

**Rd** Device Address

To identify the device connected in a modbus communication network. Selectable from 1-250.

**bR** Baud Rate Setting

Set the baud rate in a modbus communication between host computer and device. Selectable as:  
 (3 = 300, 6 = 600, 12 = 1200, 24 = 2400, 48 = 4800, 96 = 9600, 192=19200 or 384 = 38400 ) bps

**Pt** Data Parity Setting

Set the data format in a modbus communication network. All data are 8 bits with parity selectable as:

**no** = No parity    **Even** = Even parity    **odd** = Odd parity